



		STAL8TR_6e	
		STA8-AC-2V	Rev.: 2
		PAGE 69	






















.STAL8TR_7e	
.STAB-AC-2V	Rev.: 2
PAGE 7 / 9	

Limit Switches and Magnet Arrangement in the Shaft

2 SPEED ELEVATORS



	STAL8TR_8e	
	.STA8-AC -2V	Rev.: 2
PAGE 8/9		

	1	2	3	4	5	6	7	8
A			P1.G7 - PAGE ONE, AREA G7					TOGGLE SWITCH
B			TERMINAL BLOCK OF CONTROL PANEL					EMERGENCY SWITCH
C			TRAVELING CABLE					N.C. PRESSURE SWITCH
D			CONTROL BOARD POWER TERMINAL					PUSHBUTTON
E			CONTROL BOARD INPUT					KEYSWITCH
F			CONTROL BOARD OUTPUT					N.C. LIMIT SWITCH
G			CONTROL BOARD TERMINAL, INPUT / OUTPUT					PNEUMATIC TIMER CONTACT
H			RELAY COIL					MAGNETIC SENSOR
			CONTACTOR COIL					MECHANICAL INTERLOCK
			N.O. CONTACT					
			N.C. CONTACT					

		.STAL8VF_9e	
		STA8-AC-2V	Rev.: 2
		PAGE 9/9	